

Chevy Crew LT1

2007-2013

Install Instructions

CHECK FOR WIRES WHEN DRILLING!!!!!!

1. Remove Passenger side headrest. Reinstall headrest rods through long “L” bracket holes and place back into the seat back. Loosely install screened floor bracket to the lower side screen. Place lower side screen between the rear seats and to the rear. Attach Long “L” bracket to side screen through pre drilled holes.
2. Install the flat 6 ½ “bracket to the upper side screen as shown in the layout picture. Remove the headliner plug above the prisoner seat. Install the upper side screen to the lower side screen.
3. Install the upper and lower front screen brackets. Install the foam tube starting at the top of the front screen around to the front plate steel.
4. Remove the seatbelt on the passenger side. Place the front screen in the vehicle and attach the upper front screen bracket to the seat belt and replace the lug. [Seatbelt carrier on the outside with Seatbelt adjusted UP.](#)
5. With 4 bolts, attach the front screen to the side screen to include the front of the screened floor bracket.
6. Now adjust the overall placement of the entire partition, back and towards the door. Drill a small hole next to the headliner hole and install the upper rear bracket with the tap screw provided. Tighten all fasteners. Tap screw the lower front floor bracket after achieving proper clearance from the door post. Tap screw screened if you feel it's necessary.

Chevy Crew LT1

2007-2013

Install Instructions

