

# Caprice

## All Years

### Install Instructions

#### Check for Wires FIRST before drilling holes!

1. Remove Prisoner side and center cargo hook, rear deck. Using the existing 5/16 bolts and silver spacers, install the rear deck support. The (2) welded 5/16 bolts upwards and to the center of the rear deck. Loosely install the rear window bracket on the rear deck support.
2. Remove the passenger side pillar post plastic to expose the seat belt. Remove the seat belt and install the upper bracket by reinstalling the seat belt bolt. Door post plastic should not be cut if bracket is installed correctly.
3. Remove plastic cover on outside/rear seat rail. Remove bolt and install lower front screen bracket.
4. Bolt the side and front screen together. Install the foam tube on the ceiling portion of the front screen. Leave the upper front screen bracket holes exposed.
5. Carefully insert the partition in the vehicle. Attach the upper and lower front screen brackets in the pre-drilled holes. Attach the rear window bracket the upper rear side screen with (3) bolts.
6. Install the screened floor bracket to the side and front screen, using (3) bolts.
7. Align the entire partition and tighten all fasteners, seat belt, and seat rail bolt. Finish the Foam tube. The side of the front screen should be nearly touching the Prisoner door and door latch should be impossible to operate if aligned correctly.

# Caprice

All Years

Install Instructions

