

Chevy Crew  
2014-2017  
Install Instructions

**Do not tighten any bolts until assembly is complete!**

1. Fold the passenger 2/3<sup>rd</sup> seat up. Place lower side screen between the seat split, and seatbelt carrier plastic and to the rear firewall. Remove the prisoner headrest. Install headrest through the flat bracket and back into place.
2. Install foam tube to upper side screen. Bolt upper side screen to lower side screen and attach the headrest bar to the upper side screen.
3. Slide the passenger front seat forward and remove seat rail plastic covers on the outside rear (closest to the door).
4. Remove the seat rail bolt and place the lower front screen bracket between the seat rail and mounting bracket. Replace bolt. (**Do not tighten**)
5. Install foam tube to the upper portion of the front screen with Zip ties. Bolt the front screen to the side screen and loosely to the seat rail bracket.
6. Bolt the upper front screen bracket on to the front screen, bolt inside the B Pillar handle.
7. Cut off an inch of the remaining foam tube to use as a cushion for the “U” style clamp and attach to the upper front bracket on the welded bolt. Adjust your partition position as necessary and tighten all the fasteners. Finish the Foam tube.
8. The 3” bracket can be used to secure the bottom of the side screen to the drive shaft hump. (**OPTIONAL**)

[Visit our Facebook Page!](#)

