

Chevy Ex Cab

2007-2013

Install Instructions

1. Remove the headrest, prisoner rear and roof liner button. Install 16" flat bracket to side screen, ½" holes forward. Install upper 3 ½" bracket to upper rear of side screen as shown: (See Picture)
2. Slide passenger seat ahead. Place side screen into vehicle and reinstall the headrest thru the 16" flat bracket. Install the screened floor bracket to the side screen.
3. Install the upper front screen bracket and the foam tube to front screen top portion, stop just before upper seat belt bracket. Install lower right floor bracket to front screen, facing to the rear. Remove seatbelt carrier.
4. Place front screen in the vehicle and attach to the side screen, screened floor bracket and to the Seatbelt carrier to upper front screen bracket.
5. Make final adjustments by lifting side screen to roof line and towards the lower door post area. **Make sure you check for wires before drilling or punching a guide hole.** Drill a small hole for the upper rear headliner bracket and tap screw to inner roof steel thru the existing headliner hole. Check and tighten all fasteners.

Chevy Ex Cab 2007-2013 Install Instructions

