

Chevy Impala

2006-2008 & 2013-2016

Install Instructions

Inspect for wires before ANY drilling!!!

1. Bolt together the side and front screens. Install foam tube starting at the top/rear of the side screen. Fasten with zip ties around to a point where the two holes for the upper doorpost bracket holes appear on the front screen.
2. Slide passenger front seat fully ahead. Place the cage in the vehicle carefully.
3. Secure both the 2" floor bracket or flat bracket and upper seat belt bracket to the front screen. Slide the seat belt adjuster up and attach bracket by removing seat belt bolt and attaching over the post and replacing the seatbelt strap holder. Make sure the provided bracket's hole aligns with the seatbelt nut.
4. Attach the floor bracket to the side screen in the predrilled holes and securely fasten. Attach the 1" strip portion of the floor bracket to the lower front screen.
5. Install the rear window bracket with cross piece to the cargo tie downs, bolts to the front. Attach bracket to the side screen and secure with (3) 5/16th bolts. **The rear window bracket should be self-aligned, just touching the center headrest.**
6. Secure lower 2" floor bracket under the Seat Rail Bolt.
7. Push or pull entire cage towards the doorpost while holding the seatbelt height adjustment button in the unlock position. Pulling down on the seatbelt bracket/front screen will also help. This will move the cage closer to the doorpost and closer to the ceiling at the window area. Attach screened floor bracket to center hump if necessary.
8. Finish installing the foam tubing.

Chevy Impala

2006-2008 & 2013-2016
Install Instructions

