

Chevy Impala

2009-2012

Install Instructions

Check for any wires before any drilling!

- 1. Install the rear window bracket with the cross piece to the cargo tie down hooks behind the headrests, bolts to the front. Slide front passenger seat fully ahead.**
- 2. Bolt side and front screens together. Install the upper 2" bracket to the front screen along with the foam tube. Remove seatbelt carrier and right/rear seat rail bolt. Install the lower 2" bracket under the seat rail and replace the seat rail bolt. Do not tighten until end.**
- 3. Place partition in the vehicle. Attach the front screen upper bracket behind the seat belt carrier and loosely re-attach. Install the screened floor bracket to the side and front screen. Should sit on the hump.**
- 4. Install the rear window bracket to the upper-rear side screen and to the cross bracket between the cargo hooks. Bolt the lower front screen bracket to the lower right front screen. Seat belt adjuster will ease attachment and alignment of partition to ceiling and to door post. Tighten all bolts and finish the foam tube.**

[Visit our Facebook Page!](#)

Chevy Impala

2006-2008 & 2013-2016

Install Instructions

