

# Chevy Tahoe/Suburban

2015-2017

## Install Instructions

1. With the Cargo Barrier LOGO facing the front of the vehicle, loosely install the Cargo Barrier Brackets also facing forward. See Picture. With someone holding the barrier to the ceiling and against the rear seat backs, mark the side molding plastic where the barrier will attach.
2. Remove the upper plastic from both sides and install the spacer blocks as shown in attached pictures, using 2 each 1" taps. Be sure the location is correct to allow the plastic molding to return to their original position. Replace the plastic. Drill out the marks you made through the Block you just installed with a small bit.
3. Place the side screen in the vehicle, between the split in the seats.
4. Loosely install the Cargo barrier in the predrilled holes from step 2 and attach the side screen to the rear cargo barrier finger tight. Install the side screen floor bracket to the side screen. This will help hold everything in place.
5. Install the Upper front screen bracket to the screen: Tighten. Install the foam tube with Zip ties. Install the lower front screen bracket on the bottom right. Will work either direction. Place the front screen in the vehicle and attach to the side screen. Install "U" clamp around the "OH SHIT" handle and secure.
6. After aligning the partition to the door post, tighten all fasteners; tap screw the front screen bracket to the floor.

[Visit our Facebook Page!](#)

Chevy Tahoe/Suburban  
2015-2017  
Install Instructions

