

Ford Expedition

2007-2017

Install Instructions

1. Loosely install brackets to Rear Cargo Barrier with LOGO forward. Bends outward towards the rear seat belts. Attach the brackets behind the seatbelts on both sides.
2. Slide the front passenger seat forward. Bolt together the 2 pc. Side screen together as picture shows. Place side screen in vehicle and install to the rear cargo barrier.
3. Install the 13 ½” “Pillar post” seatbelt bracket to the front screen and attach the foam tube to the upper portion of the front screen with the ties provided. Place the front screen in the vehicle and attach to the side screen.
4. Install the 4” screened floor bracket to the side screen and front screen.
5. Install the floor bracket under the outside seat rail and replace the bolt. Attach the bracket to the side screen. Push the screen toward the door and tighten the floor bracket.
6. Tap screw the screened floor bracket thru the drive shaft hump. **Watch for wires if drilling.** Tighten all bolts on the front, side, and cargo barrier.

Recommended: Zip-tie headrest of Prisoner section to Cargo barrier or remove the seat tilt handle entirely.

Ford Expedition

2007-2017

Install Instructions

