

## Suburban Cargo Barrier Install

1. Loosely attach the 14 ½” and 15 1/2 ” “L” brackets with to barrier screen as shown in the picture.
2. Install Support legs, Attachment tab to inside of vehicle bed.
3. Place screen in vehicle, and attach upper brackets to seatbelt lugs. (May have to bend brackets to flush with plastic moldings.) Replace seatbelts and snug nut.
4. Align screen up and down and drill or punch hole for tap screws through legs. Watch out for wires/gas tank, etc.
5. Tighten upper brackets to screen.

